



Firmware upgrade manual
for
GOODRAM SSDPR-PX500-xxx-80 FW: U0806A0

1. Check the current version of the SSD's FW by running Optimum SSD Tool or other application. If U0806A0 is displayed as current FW version, go to the next step.



2. Run file: "Firmware_upgrade_PX500_U0806U0_20230324.exe" and wait until black windows is closed.



3. Perform power off/on cycle of the computer for new firmware activation.
4. Run Optimum SSD Tool or other application for checking FW version. Firmware version should be U0806U0.

